



EFFICACY DATA for SANIMASTER 6 Sanitizer/Disinfectant (EPA Reg. No. 1839-166-79687)

VIRUCIDAL DATA:

Test Methods:

- * U.S. E.P.A. Pesticide Assessment Guidelines, Subdivision G: Product Performance, Section 91-2 (f), and Section 91-30, (d), (e), November 1982.
- † Protocols for Testing the Efficacy of Disinfectants against Hepatitis B Virus (HBV) (EPA, Federal Register, Vol. 65, No. 166, 8/25/2000, p. 51828).
- ‡ Protocol for Testing Disinfectants against Hepatitis C Virus using Bovine Viral Diarrhea Virus as approved by the U.S. EPA on August 15, 2002.

Test Conditions: 10 minute contact time, 5% organic soil load, sterile glass petri dishes, 400 ppm hard water, 21-24°C exposure temperature, 1 oz/gal dilution

Results:

Test Organism	Sample		Titer Reduction	
	A	B	A	B
*Avian Influenza A Virus (H3N2) (Avian Ressorant) (ATCC VR-2072)	A	B	>4.25 log ₁₀	>4.25 log ₁₀
*Avian Influenza Virus, Type A (Turkey/WIS/66) (H9N2)	A	B	>4.0 log ₁₀	>4.0 log ₁₀
‡Bovine Viral Diarrhea Virus (BVDV)	A	B	5.9 log ₁₀	5.9 log ₁₀
*Canine Distemper, strain Lederle (ATCC VR-128)	A	B	>6.25 log ₁₀	>6.25 log ₁₀
*Feline Picornavirus, strain FRV (ATCC VR-649)	A	B	>4.25 log ₁₀	>4.25 log ₁₀
†Hepatitis B Virus (HBV) (Duck Hepatitis B Virus-DHBV)	A	B	4.5 log ₁₀	4.7 log ₁₀
‡Hepatitis C Virus (HCV) (Bovine Viral Diarrhea Virus-BVDV)	A	B	5.9 log ₁₀	5.9 log ₁₀
*Herpes Simplex Type 1 (ATCC VR-260)	A	B	>5.0 log ₁₀	>5.0 log ₁₀
*Herpes Simplex Type 2 (ATCC VR-734)	A	B	>6.0 log ₁₀	>6.0 log ₁₀
*Human Coronavirus (ATCC VR-740, strain 229E)	A	B	>3.0 log ₁₀	>3.0 log ₁₀
*Human Immunodeficiency Virus, HTLV-III _{RF} , strain of HIV-1 (associated with AIDS)	A	B	>3.5 log ₁₀	>3.5 log ₁₀
*Human Immunodeficiency Virus type 2 (HIV-2), strain CBL-20	A	B	>3.25 log ₁₀	>3.25 log ₁₀
*Infectious Bovine Rhinotracheitis, strain LA (ATCC VR-188)	A	B	>5.0 log ₁₀	>5.0 log ₁₀
*Influenza A ₂ , strain Hong Kong (ATCC VR-544)	A	B	>4.25 log ₁₀	>4.25 log ₁₀
*Pseudorabies, strain Aujeszky (ATCC VR-135)	A	B	>5.25 log ₁₀	>5.25 log ₁₀
*Rotavirus, strain SA-11 (ATCC VR-899)	A	B	4.5 log ₁₀	4.5 log ₁₀
*SARS Associated Coronavirus (ZeptoMetrix)	A	B	3.03 log ₁₀	3.03 log ₁₀
*Vaccinia, strain WR (ATCC VR-119)	A	B	>5.5 log ₁₀	>5.5 log ₁₀

Conclusion: Under the conditions of this investigation, this product was **virucidal** for Avian Influenza A Virus (H3N2), Avian Influenza Virus, Type A (H9N2), Bovine Viral Diarrhea Virus (BVDV), Canine Distemper, Feline Picornavirus, Hepatitis B Virus (HBV), Hepatitis C Virus (HCV), Herpes Simplex Type 1, Herpes Simplex Type 2, Human Coronavirus, Human Immunodeficiency Virus (HIV-1), Human Immunodeficiency Virus Type 2 (HIV-2), Infectious Bovine Rhinotracheitis, Influenza A₂, Pseudorabies, Rotavirus, SARS Associated Coronavirus and Vaccinia according to criteria established by the U. S. Environmental Protection Agency for registration and labeling of a disinfectant product as a virucide.

EFFICACY DATA for SANIMASTER 6 Sanitizer/Disinfectant (EPA Reg. No. 1839-166-79687)

MILDEW FUNGISTATIC DATA:

Test Method: Hard Surface Mildew Fungistatic Test

Test Organism: *Aspergillus niger* (ATCC 6275)

Test Conditions: 400 ppm hard water, ceramic tile carriers, 1 oz/gal dilution

Results:

Sample	No. of Exposed Tiles	No. of Tiles Showing Growth
A	10	0
B	10	0
Control	10	10

Conclusion:

Under the conditions of this investigation, this product was **fungistatic** for *Aspergillus niger* according to criteria established by the U. S. Environmental Protection Agency for registration and labeling of a disinfectant product as a fungistat.

FUNGICIDAL DATA:

Test Method: AOAC Fungicidal Activity of Disinfectants

Test Conditions: 5% organic soil load, 20°C exposure temperature, 200 ppm hard water, 1 oz/gal dilution

Results:

Test Organism	Exposure Time (min.) vs. Growth			
	Sample	5	10	15
<i>Trichophyton mentagrophytes</i> (ATCC 9533)	A	+	0	0
	B	+	0	0
<i>Candida albicans</i> (ATCC 10231)	A	0	0	0
	B	0	0	0

Conclusions:

Under the conditions of this investigation, this product was **fungicidal** for *Trichophyton mentagrophytes* and *Candida albicans* according to criteria established by the U. S. Environmental Protection Agency for registration and labeling of a disinfectant product as a fungicide.

EFFICACY DATA for SANIMASTER 6 Sanitizer/Disinfectant (EPA Reg. No. 1839-166-79687)

DISINFECTION DATA:

Test Method: AOAC Use Dilution

Test Conditions: 5% organic soil load, 10 minute contact time, stainless steel carrier substrates, 400 ppm hard water, 20°C exposure temperature, 1 oz/gal dilution

Results:

Test Organism	Sample	No. of Carriers Exposed	Positive
<i>Staphylococcus aureus</i> (ATCC 6538)	A	60	1
	B	60	1
	C	60	1
<i>Salmonella enterica</i> (ATCC 10708)	A	60	0
	B	60	0
	C	60	1
<i>Pseudomonas aeruginosa</i> (ATCC 15442)	A	60	0
	B	60	0
	C	60	1
<i>Bordetella bronchiseptica</i> (ATCC 31437)	A	10	0
	B	10	0
Community Associated Methicillin Resistant <i>Staphylococcus aureus</i> (CA-MRSA) (NRS 123, Genotype USA400)	A	10	0
	B	10	0
	C	10	0
Community Associated Methicillin Resistant <i>Staphylococcus aureus</i> (CA-MRSA) (NRS 384, Genotype USA300)	A	10	0
	B	10	0
	C	10	0
<i>Corynebacterium ammoniagenes</i> (ATCC 6871)	A	10	0
	B	10	0
<i>Enterobacter aerogenes</i> (ATCC 13048)	A	10	0
	B	10	0
<i>Enterobacter cloacae</i> (ATCC 23355)	A	10	0
	B	10	0
<i>Enterobacter cloacae</i> (clinical isolate)	A	10	0
	B	10	0
<i>Enterococcus faecalis</i> (ATCC 19433)	A	10	0
	B	10	0
<i>Enterococcus faecalis</i> (clinical isolate)	A	10	0
	B	10	0
<i>Escherichia coli</i> (ATCC 11229)	A	10	0
	B	10	0
<i>Escherichia coli</i> (clinical isolate)	A	10	0
	B	10	0
<i>Fusobacterium necrophorum</i> (ATCC 27852)	A	10	0
	B	10	0

DISINFECTION DATA (continued):

	No. of Carriers			
Test Organism		Sample	Exposed	Positive
<i>Klebsiella pneumoniae</i> subsp. <i>pneumoniae</i> (ATCC 13883)		A	10	0
		B	10	0
<i>Listeria monocytogenes</i> (ATCC 35152)		A	10	0
		B	10	0
Methicillin Resistant <i>Staphylococcus aureus</i> (MRSA) (ATCC 33592)		A	10	0
		B	10	0
<i>Pasteurella multocida</i> (ATCC 7707)		A	10	0
		B	10	0
<i>Proteus mirabilis</i> (ATCC 9921)		A	10	0
		B	10	0
<i>Proteus mirabilis</i> (ATCC 25933)		A	10	0
		B	10	0
<i>Proteus vulgaris</i> (ATCC 13315)		A	10	0
		B	10	0
<i>Salmonella enterica</i> subsp. <i>enterica</i> serotype <i>paratyphi</i> (ATCC 8759)		A	10	0
		B	10	0
<i>Salmonella enterica</i> subsp. <i>enterica</i> serotype <i>pullorum</i> (ATCC 9120)		A	10	0
		B	10	0
<i>Salmonella enterica</i> subsp. <i>enterica</i> serotype <i>typhi</i> (ATCC 6539)		A	10	0
		B	10	0
<i>Salmonella enterica</i> subsp. <i>enterica</i> serotype <i>typhimurium</i> (ATCC 14028)		A	10	0
		B	10	0
<i>Serratia marcescens</i> (ATCC 8100)		A	10	0
		B	10	0
<i>Shigella dysenteriae</i> (ATCC 12180)		A	10	0
		B	10	0
<i>Shigella flexneri</i> Type 2b (ATCC 12022)		A	10	0
		B	10	0
<i>Shigella sonnei</i> (ATCC 25931)		A	10	0
		B	10	0
<i>Staphylococcus aureus</i> subsp. <i>aureus</i> (ATCC 33592)		A	10	0
		B	10	0
<i>Staphylococcus aureus</i> (clinical isolate)		A	10	0
		B	10	0
<i>Staphylococcus epidermidis</i> (ATCC 29641)		A	10	0
		B	10	0
<i>Staphylococcus epidermidis</i> (clinical isolate)		A	10	0
		B	10	0
<i>Streptococcus pyogenes</i> Group A (ATCC 19615)		A B	10 10	0 0

DISINFECTION DATA (continued):

Test Organism	No. of Carriers	Sample	Exposed	Positive
<i>Streptococcus pyogenes</i> (clinical-flesh eating strain, BIRD M3)		A	10	0
		B	10	0
Vancomycin Resistant <i>Enterococcus faecalis</i> (VRE) (ATCC 51575)		A	10	0
		B	10	0
Vancomycin Intermediate Resistant <i>Staphylococcus aureus</i> (VISA) (HIP-5836)		A	10	0
		B	10	0

Conclusion: Under the conditions of these investigations, this product demonstrated **disinfectant** activity against *Staphylococcus aureus*, *Salmonella enterica*, *Pseudomonas aeruginosa*, *Bordetella bronchiseptica*, Community Associated Methicillin Resistant *Staphylococcus aureus* (CA-MRSA) (NRS 123, Genotype USA400), Community Associated Methicillin Resistant *Staphylococcus aureus* (CA-MRSA) (NRS384, Genotype USA300), *Corynebacterium ammoniagenes*, *Enterobacter aerogenes*, *Enterobacter cloacae*, *Enterococcus faecalis*, *Escherichia coli*, *Fusobacterium necrophorum*, *Klebsiella pneumoniae* subsp. *pneumoniae*, *Listeria monocytogenes*, Methicillin Resistant *Staphylococcus aureus* (MRSA), *Pasteurella multocida*, *Proteus mirabilis* (ATCC 9921), *Proteus mirabilis* (ATCC 25933), *Proteus vulgaris*, *Salmonella enterica* subsp. *enterica* serotype *paratyphi B*, *Salmonella enterica* subsp. *enterica* serotype *pullorum*, *Salmonella enterica* subsp. *enterica* serotype *typhi*, *Salmonella enterica* subsp. *enterica* serotype *typhimurium*, *Serratia marcescens*, *Shigella dysenteriae*, *Shigella flexneri* Type 2b, *Shigella sonnei*, *Staphylococcus aureus* subsp. *aureus*, *Staphylococcus epidermidis*, *Streptococcus pyogenes* Group A, *Streptococcus pyogenes* (clinical-flesh eating strain, BIRD M3), Vancomycin Resistant *Enterococcus faecalis* (VRE), and Vancomycin Intermediate Resistant *Staphylococcus aureus* (VISA), according to criteria established by the U. S. Environmental Protection Agency for registration and labeling of a disinfectant product as a bactericide.

This product also demonstrated disinfectant activity against the following antibiotic resistant clinical isolates: *Enterobacter cloacae*, *Enterococcus faecalis*, *Escherichia coli*, *Staphylococcus aureus*, and *Staphylococcus epidermidis*.

Nothing contained herein grants or extends a license, express or implied, in connection with patents, issued or pending, of the manufacturer or others. The information contained herein is based on the manufacturer's own study and the works of others. The manufacturer makes no warranties, expressed or implied, as to the accuracy, completeness, or adequacy of the information contained herein. The manufacturer shall not be liable (regardless of fault) to the vendee's employees, or anyone for any direct, special or consequential damages arising out of or in connection with the accuracy, completeness, adequacy or furnishing of such information.

02/27/08